

Place Templates Here

Run .75" masking tape below templates.
Align decals beneath tape line.
Align points of star below tape line.



**21 Tahoe
Passenger Quarter
Run 3/4" Tapeline Below**

**21 Tahoe
Driver Fender**

Run 3/4" Tapeline Below

**21 Tahoe
Driver Quarter**

Run 3/4" Tapeline Below

Run 3/4" Tapeline Below

**21 Tahoe
Passenger Fender**